


Seeing the Contents of a Skid

1 Open the Action Target Enterprise Portal.


The screenshot displays the Action Target Enterprise Portal interface. A navigation menu is open, listing various modules: Potool (Purchase Order Manager), Sourcing, Vendbid (Vendor Bid Pricing), Vendim (Vendor Info Manager), Planning, Work Orders, Lift Trucks, Receiving, Inventory Management, Shop Manager, Shop Tracker, Shop Clock, Quality, and Manufacturing Docs. The footer contains four main sections: Employee Directory, Status, Message Center, and Browser Support. The Employee Directory section includes a search box for 'Employee Name' and a table with columns for 'Employee Name', 'Phone Number', and 'Actions'. The Status section lists system components: Data Warehouse, Email / Office 365, ERP Legacy Apps, ERP Web Apps, and Internet. The Browser Support section provides information on preferred, supported, and limited browsers.

Employee Directory			Status	Message Center	Browser Support
Employee Name			<ul style="list-style-type: none">Data WarehouseEmail / Office 365ERP Legacy AppsERP Web AppsInternet		Preferred: Microsoft Edge Supported: Mozilla Firefox 4, Google Chrome Limited: Microsoft Internet Explorer 3 <small>1 Does not support launching ECH Manager or Single 2 Does not support launching ECH Manager</small>
Employee Name	Phone Number	Actions			

2 Click on the "Supply Chain" menu located near the top of the screen.



3 Click the "Shop Tracker" option from the drop-down menu.



4 Click on the "Material" tab near the top of the tool.

Shop Tracker

Schedule Setup Time **Material** Staging

Schedule

Operator Actions: Check In, Check Out, Documents, Fulfill, EHR, Labels, Add Destination, Close Job, QC

Search: Queued, Kitting, **Staged**, In-Process, Parts in Batch, Work Order

Priority	WO ID	MTR	Req Qty	Part Number	Description	Operation	WO Notes	Start	Status	Batch ID	Mat Available	Next Op Name	WO Due
5		jb-1055-1	1	49135	(Phase-Out - R	elec-asmemb	Inspect Repc	2025-03-07	staged		true		
6	58793	mo-170454	4	33785	-REDLINE- Aut	elec-asmemb	Indonesia 2C	2025-03-27	in-process	14637	false		2025-05-12
6	58794	mo-170454	4	33785	-REDLINE- Aut	elec-asmemb	Indonesia 2C	2025-03-27	in-process	14637	false		2025-05-12
6	58695	mo-170270	15	33785	-REDLINE- Aut	elec-asmemb	Indonesia 2C	2025-03-27	in-process	14636	true		2025-04-28
6	58697	mo-170270	4	33785	-REDLINE- Aut	elec-asmemb	Indonesia 2C	2025-03-27	in-process	14636	false		2025-04-28
6	59693	mo-172027	1	33785	-REDLINE- Aut	elec-asmemb	WAR Ord 15	2025-03-27	in-process	14637	true		2025-05-19
6	58899	mo-170628	15	33785	-REDLINE- Aut	elec-asmemb	Israel-IMI 15	2025-03-27	in-process	14637	false		2025-05-16
6	58702	mo-170288	16	33785	-REDLINE- Aut	elec-asmemb	Indonesia 2C	2025-03-27	in-process	14636	false		2025-05-12

5 Select your desired skid from the skid map in the PandD window.

Shop Tracker

Schedule Setup Time **Material** Staging

Select an MO in Main Tab: Check Out, Remnant

Content Skids

No data loaded

Skid	Part Number	Qty						
A0a	1695	3243						
	0-0-3	0-0-2	0-0-1	0-0-0				
A0d								
	0-1-2	0-1-1	0-1-0					
A0f								
	0-0-1	0-0-0						
A0g								
	0-1-2	1557	4641					
	1032							
	0-0-2	0-0-1	0-0-0					
A1e	3125	4529	1516		1348	2023		
	0-1-0	0-1-1	0-1-2	1-1-0	1-1-1	1-1-2		
	3127	3936			4067	2971		
	0-0-0	0-0-1	0-0-2	1-0-0	1-0-1	1-0-2		
B1c	2433	1484		4620	3175	4046		
	0-1-0	0-1-1	0-1-2	1-1-0	1-1-1	1-1-2		
	3396	4453		3000	2923	1444		
	0-0-0	0-0-1	0-0-2	1-0-0	1-0-1	1-0-2		
M0c		4511	4311	4311		4529	3125	
	0-0-0	0-0-1	0-0-2	0-0-3	0-0-4	0-0-5	0-0-6	0-0-7
	0-0-4	4163	4163	4242				
	0-0-4	0-0-3	0-0-2	0-0-1	0-0-0			

119 - Electronics Flammables Cabinet

6 Click the "Preview Contents" option from the dropdown menu.

Schedule Setup Time **Material** Staging Work Cell: | pi

Select an MO in Main Tab Check Out Remnant

Content Skids
 No data loaded

A0a	1695	3243			A0d				A0f			A0g		1557	4641
	0-0-3	0-0-2	0-0-1	0-0-0		0-1-2	0-1-1	0-1-0		0-0-1	0-0-0		0-1-2	0-1-1	0-1-0
						0-0-2	0-0-1						1032		
						0-0-2	0-0-1						0-0-2	0-0-1	0-0-0

A1e	3125	4529	1516		1348	2023
				1-1-0	1-1-1	1-1-2
					4067	2971
				1-0-0	1-0-1	1-0-2

Cancel Request

Store Skid

B1c				4620	3175	4046
				1-1-0	1-1-1	1-1-2
				3000	2923	1444
				1-0-0	1-0-1	1-0-2

Check Skid Out

Load Skid

Preview Contents

M0c			4311		4529	3125		
	0-0-0	0-0-1	0-0-2	0-0-3	0-0-4	0-0-5	0-0-6	0-0-7

M1c			4163	4163	4242	
	0-0-4	0-0-3	0-0-2	0-0-1	0-0-0	

119 - Electronics Flammables Cabinet

Search Edit Edit Skid Show Skids Clear Selection Transfer Refresh

Search: Skid Part Ponum Shop Job Search

Locations with Part Search Multi Selection Actions Transfer

Search: Location ID Part Search

Skid ID	WIP Count	Part ID	Part Number	Description	PO Number	PO Item	Seque

Location ID	Location	WIP Count	Part

7 Scroll down to view the skid contents list.

8

The skid contents list is now populated with all the parts on the selected skid.

This is a test environment. All changes are isolated to the testing environment.

The interface consists of two main panels. The top panel shows a grid of skid locations with various part numbers. The bottom panel is divided into two sections: 'Contents' and 'Locations with Part'. The 'Contents' section contains a table with columns for 'd ID', 'WIP Count', 'Part ID', 'Part Number', 'Description', 'PO Number', 'PO Item', and 'Seque'. The 'Locations with Part' section is currently empty, displaying 'No data loaded'. A red arrow points from the 'Locations with Part' section towards the 'Contents' table.

d ID	WIP Count	Part ID	Part Number	Description	PO Number	PO Item	Seque
5	29	12897	12897	Mancom New			49
5	30	11967	11967	Mancom LAT			48
5	75	11628	11628	Mancom Clam			47
5	75	11629	11629	Mancom Clam			46
5	596	18120	18120	64MBLACK BL			45
5	256	37251	37251	Clamping Sha			41
5	52	12893	12893	Mancom Turn			39
5	49	11966	11966	Mancom LAT			21
5	103	11627	11627	Mancom Clam			19
5	179	11633	11633	Mancom Clam			13
5	111	11956	11956	Mancom LAT			7