

# How To: Clear print queue on Zebra printers

## “ Purpose

This guide walks through the process of clearing print queues on Zebra Printers

## Step-by-Step Instructions

1. Leave the Zebra printer on and running.

It will keep printing, and the status light will be solid red or flashing red.

2. Press and hold the blue button on the top of the Zebra printer for ~5-10 seconds until the status light flashes, then release.

image.png

3. Ensure the light on the Zebra turns to solid green. The printer is ready to print again!

The solid green status light indicates the print queue was cleared and is ready to be used again.

## Validation

Ensure the status light turns to solid green

---

## ☐ Cleanup (if applicable)

Trash unneeded excess prints

---

## ☐ Additional Notes & FAQ

---

“ ☐ **Last reviewed:** 2025-09-22

**Author:** Tanner Bench

**Related Tags:** How-To:

---

Revision #2

Created 22 September 2025 19:28:29 by Tanner Bench

Updated 22 September 2025 19:30:46 by Tanner Bench